



- LIST OF WIRING HARNESSES -

A	: Engine front harness	K	: Electric window winder harness (R. 1151-R. 1154-R. 1156)
B	: Combination lighting-direction ind. switch	L	: L.H. window winder motor harness (R. 1151-R. 1154-R. 1156)
C	: Instrument panel harness (R. 1150-R. 1152-R. 1153)	M	: R.H. window winder motor harness (R. 1151-R. 1154-R. 1156)
D	: Rear harness	N	: Sunroof motor harness
E	: Interior light-sunroof harness	O	: Alternator harness
F	: Q.I. headlights relay harness (R. 1151-R. 1154)	P	: Positive lead
G	: Sunroof-electric window winder relay harness	Q	: Negative lead
H	: L.H. electric window winder - L.H. front door electro-magnetic lock harness (R. 1151-R. 1154-R. 1156)	S	: Automatic transmission harness (R. 1153-R. 1154-R. 1155)
I	: R.H. electric window winder - R.H. front and rear door electro- magnetic lock harness (R. 1151-R. 1154-R. 1156).	T	: L.H. rear door electro-magnetic lock harness
		U	: Air conditioning system harness

- WIRE IDENTIFICATIONS -

Each wire is identified by a number followed by letter(s) indicating the wire and sleeve colours, if fitted, and a number indicating the diameter.

Wire and sleeve colours											
Beige	White	Blue	Clear	Grey	Yellow	Black	Pink	Red	Green	Maroon	Violet
Be	Bc	B	C	G	J	N	S	R	V	M	Vi

Wire diameters						
No.	1	2	3	4	5	6
mm	9/10	12/10	16/10	20/10	25/10	30/10
Gauge	19	16	14	12	10	9

Example

No.	Wire colour	Sleeve colour	Diameter
10	Bc	B	1